

ReadyCare™

HOTEL • SPA • CLUB • GOLF



Dovetail

SHOWER & VANITY DISPENSERS



Installation Guide

for Dovetail Dispensers

Your Partner for Personal Care Solutions



Prior To Installation





Before You Install Your EcoEclipse Dispenser

- Read these instructions thoroughly before starting your installation.
- You will need clear adhesive caulk, rubbing alcohol (isopropyl), a level and masking tape.
- After installation, wait a minimum of 12 hours before inserting filled bottles into your Dove Tail dispenser.
- Mount brackets in a test bathroom to test the tile adhesion prior to the entire hotel.
- Don't worry. Many properties have successfully installed our Dove Tail dispenser, and you will too.




Steps 1 - 2, Bracket Installation



1) Placing template on wall.

Decide how high up you want your dispenser. The recommended height is 48" from the floor to the base of the dispenser on the opposite wall from the shower head. For disability showers please refer to you local rules.


Also make sure the installation surface is clean and dry. Grime or soap scum will decrease the effectiveness of the adhesive and could cause the dispenser to not adhere properly. **Use rubbing or isopropyl alcohol for final prep and wait for surface to fully dry before applying brackets.**




2) Make sure template is level.

Be sure to align at least 3" from wall or glass door.


Steps 3 - 5, Bracket Installation



3) Tape template corners.




4) Remove double sided tape.



5) Place bracket in slot one of template (starting bottom first).



Steps 6 - 8, Bracket Installation



6) Press firmly for 30 seconds to ensure double sided tape adhesion.




7) Repeat process for slots 2 & 3.



8) Remove template.

Press firmly on each bracket for 30 seconds.

Steps 9 - 10, Bracket Installation



9) Apply clear adhesive caulk around top and sides of brackets.

We recommend placing an aggressive bead of clear adhesive caulk around the top and sides and firmly pressing into sides of brackets (do not apply to bottom of bracket). This will prevent soap grime from getting behind the unit. Wipe away any excess caulk. **Wait for 12 hours before inserting bottles. This allows tape to set up.**



10) Insert bottles, after 12 hours.



Bottle Removal



Step 1) Place key flush with wall and to the center of the dispenser.



Step 2) Push upward to release locking mechanism.



Step 3) Pull bottle straight up to remove.

ReadyCare™

HOTEL • SPA • CLUB • GOLF



Dovetail

SHOWER & VANITY DISPENSERS



About ReadyCare

ReadyCare is a leading provider of personal care amenities, supplies and private label solutions to world-class hotels, spas, health clubs and golf clubs. For over 25 years, Denver-based ReadyCare has helped thousands of properties deliver great member and guest experiences by ensuring their personal care offering aligns with their brand and their customers.

Your Partner for Personal Care Solutions



2-24-19

(800) 477-4283 • info@readycare.com • www.readycare.com